

Safety measures when testing lithium-ion batteries

Dominik Ludewig

Head of Technical Sales

SEES Autumn Meeting 2022











Founded in 1913 by Ludwig Schunk

No shareholders. Foundation based.

2 Divisions: Materials Science and Mechanical Engineering (incl. weisstechnik)









Environmental Simulations




Heat Technology



Air Solutions




Pharma






Consulting > Engineering > Production > Installation > Training > Service





There for you. Worldwide.

- Service centers in Europe, Asia, and America
- Shorter response times
- High qualified employees
- Qualification / Re-qualification











Introduction to our safety approach Hazard potentials of lithium-ion batteries



Introduction to our safety approach Hazard potentials of lithium-ion batteries





- EUCAR Hazard Levels define criteria and effects of lithium-ion battery failure
- Used in our checklist to determine possible risks
- Does not take battery design and seize into consideration

Hazard Level	Description	Classification criteria & effect
0	No effect	No effect. No loss of functionality.
1	Passive protection activated	No defect; no leakage; no venting, fire or flame; no rupture; no explosion; no exothermic reaction or thermal runaway. Cell reversibly damaged. Repair of protection device needed.
2	Defect/Damage	No leakage; no venting, fire or flame; no rupture; no explosion; no exothermic reaction or thermal runaway. Cell irreversibly damaged. Repair needed.
3	Leakage Δ mass <50%	No venting, fire or flame; no rupture; no explosion. Weight loss <50% of electrolyte weight (electrolyte = solvent + salt).
4	Venting Δ mass ≥50%	No fire or flame; no rupture; no explosion. Weight loss ≥50% of electrolyte weight (electrolyte = solvent + salt).
5	Fire or flame	No rupture; no explosion (i.e. no flying parts).
6	Rupture	No explosion, but flying parts of the active mass.
7	Explosion	Explosion (i.e. disintegration of the cell).



- Commonly used liquid electrolytes are flammable / explosive
- Potential risk of explosion in confined spaces

Substance	Composition	Flash point	Ignition	LEL Lower Explosion Limit	UEL Upper Explosion Limit
Ethylene carbonate (EC)	$C_3H_4O_3$	145°C	465°C	3.6 Vol.%	16.1 Vol.%
Diethyl carbonate (DEC)	C ₅ H ₁₀ O ₃	25°C	445°C	1.4 Vol.%	11.7 Vol.%
Dimethyl carbonate (DMC)	C ₃ H ₆ O ₃	18°C	458°C	4.2 Vol.%	12.8 Vol.%
Ethyl methyl carbonate (EMC)	C ₄ H ₈ O ₃	25°C	440°C	2.0 Vol.%	-
Propylene carbonate (PC)	C ₄ H ₆ O ₃	135°C	455°C	1.9 Vol.%	14.3 Vol.%


Decomposition products: C₂H₄, C₂H₆, CH₄, H₂, CO, CO₂



With weisstechnik you reliably meet the required Directives

Name	EUCAR	Machinery Directive	ATEX Directive
Directive	Guideline only	2006/42/EC	2014/34/EU
Legal situation	Not legally binding	Mandatory for	CE certification
Classification	Hazard Level 0-7	< LEL No explosive atmosphere	> LEL Explosive atmosphere









Custo	mer:		Project/Order:		
Autho	or:		Date:		
			1		
		Che	cklist		
1.	Does the customer	know the type of energy	storage?		
	Li-lon	Metal hydride →	Metal hydride → Attention: ATEX necesarry.		
		(Please ask ATEX prod	uct specialist in headquarters.)		
	Supercap	-	ention: ATEX necesarry.		
		(Please ask ATEX prod	uct specialist in headquarters.)		
	Ц				
2.	_	totype or (almost) series	T		
	Prototype		(Almost) series product		

- Used for customer projects
- Considers qualitative battery aspects
- Evaluation of the EUCAR Hazard Level
- Evaluation of ATEX





EUCAR Hazard Level 0-3 Hazard: general hazards







Status indicator



Introduction to our safety approach EUCAR Hazard Level ≥ 4

EUCAR Hazard Level ≥ 4 Hazard: overpressure



Mechanical door lock, retaining clamps, particle blocker

Reversible pressure release flap - lower pressure level -

Certified burst disc - higher pressure level -

Reinforced inner container and door



Introduction to our safety approach EUCAR Hazard Level 5

EUCAR Hazard Level 5 Hazard: fire or flame





Temperature sensor



Smoke detector



CO sensor



Safety is a question of technology EUCAR Hazard Level 5

EUCAR Hazard Level 5 Hazard: fire or flame







Water flushing system

Low pressure water sprinkler system

High pressure water mist system



Introduction to our modular safety approach Explosion protection (ATEX)

Explosion protection (ATEX)
Hazard: release of flammable / explosive gases





H2 sensor with LEL monitoring

HC sensor with LEL monitoring



Ventilation - primary Ex protection -



Nitrogen inertisation incl. O2 sensor - primary Ex protection -



Limitation of the heater's surface temperature - secondary Ex protection -



Introduction to our modular safety approach Combination with various chamber designs













Abuse tests are required for market entry

Test standards 🚉








UN ECE R100 – Battery electric vehicle safety

Stress





















Testing



Box design

- Pressure and temperature resistance
- Materials selection
- Contamination issues
- Explosion flap
- Ventilation concept

Exhaust gas purification


- Pressure management
- Adsorption scrubber and filtering

Air flow simulation

- Air distribution
- Combustion and explosion
- Pressure estimation
- Temperature gradients
- Resistance

Explosion tests

- Safety tests
- Issue certificate
- Validation









Video





Video



- weisstechnik: walk-in chamber and container
- DSA: software / electric
- ZF: cycler type VES 1000V/1000A
- Lauda: media cooling and chiller
- Callies / Systeex: high pressure water mist system






- Standardized plug & play solution, easy to install
- All from one single source
- weisstechnik clarifies all interfaces for all necessary equipment and suppliers
- Training of employees in our weisstechnik Academy
- Factory acceptance test at weisstechnik
- Fast start of first tests



- Containers from 3 to 18 meters in length can be manufactured
- Depending on the application, containers can be connected to create large rooms
- Containers can be placed side by side or on top of each other
- The Plug & Play Test Lab can be equipped with small cabinets or a walk-in chamber
- ¬ Different applications are possible like temperature tests, climate tests, corrosion tests, dust tests, etc.







- The Plug & Test Lab is delivered by truck
- All that is required is an available parking space or a strip foundation
- Electricity, water and sewage are the connection points













































Thank you for your attention!

dominik.ludewig@weiss-technik.com



Disclaimer

This document is copyright protected. It was created exclusively for information, training and further education purposes and is intended for your personal use only. Any other use of the presentation, be it in whole or in part, in particular the duplication and distribution of the presentation to third parties, requires our prior written consent. Violations of the copyright law have legal consequences under civil and criminal law.

Weiss Technik GmbH

Greizer Straße 41 - 49 35447 Reiskirchen ¬ Germany Tel +49 6408 84-0 info@weiss-technik.com www.weiss-technik.com